
Installation Instructions



- Cut the coax clean and flush. Slide cover ring, O-ring and larger coupling ring onto cable, threads facing connector. RG-58 only: place nylon adapter over end of coax.
- Push coax into the connector. Be sure connector's center pin penetrates the center conductor.
- Using pliers, carefully and evenly squeeze opposite pairs of the piercing fingers (on the knurled points) through the coax's outer jacket and into the shield.
- Slide O-ring up to the piercing fingers, tighten cover ring over fingers and screw the larger coupling ring onto the connector body.

U.S. Patents Re.36,700 /6,062,897 /6,123,567 International Patents & Patents Pending Centerpin is a registered trademark of Centerpin Technology, Inc.