

Thank you for purchasing a Shakespeare antenna product. Customer comments are welcome. Before installing, please study the diagram and check parts supplied against those listed.

**IMPORTANT! Please read all instructions before installing.**

The Styles 4008, 4008-4, and 4008-13 are heavy-duty extension masts of 1½” diameter with 1” 14-thread upper male and lower female chrome-plated brass fittings. The Style 4008 is an 8’ (2.4 m) extension mast. Style 4008-4 is a 4’ (1.2 m) version, and the Style 4008-13 is a 13’ (4 m) version. Actual lengths are 91” (231.1 cm), 50” (127 cm), and 162” (411.5 cm), respectively.

**Tools required:** None.

### Installation Instructions

Choose a mounting location appropriate to the device you will attach to the extension mast. Be sure to follow mounting location suggestions included with the device.

For antennas, the recommended mount is Shakespeare’s Style 409-R or 410-R Mounting kit (each sold separately). Attach the extension mast to the antenna before mounting the antenna.


1. Thread the antenna’s or device’s cable through the Extension Mast and through the nylon bushing on the extension’s bottom ferrule, if required.
2. Attach the antenna to the Extension Mast and hand tighten securely. Be careful not to damage or strain the cable.
3. Mount the mast and antenna/device assembly using a Shakespeare 409-R or Style 410-R Mounting Kit (each sold separately) according to the directions included with the mount you choose.

**IMPORTANT:** If using the Style 4008-4 extension mast results in more than a 10’ (3 m) antenna/mast assembly, DO NOT use a ratchet-type mount – you MUST use a Style 408-R or 409-R kit (each sold separately) with upper support bracket. In *all* cases where the antenna/extension assembly is more than 10’ you MUST use an upper support bracket such as Shakespeare Style 408-R (sold separately), mounted at least 3 to 5 feet (.9 m to 1.5 m) from the bottom of the antenna.

4. Route the antenna’s or device’s cable to your transceiver or other device. For cable routing, follow the instructions included with your device.

### Cleaning Instructions

To clean the extension mast, use mild dishwashing liquid (one that is not harsh to the hands and *without* ammonia) in lukewarm water.



35-90-1090-00

### Shakespeare Electronic Products Group

U.S. Operations: 6111 Shakespeare Rd. · Columbia, SC 29223 · 803-227-1590 · Fax: 803-419-3099 · [www.shakespeare-marine.com](http://www.shakespeare-marine.com)

U.K. Operations: Enterprise Way, Fleetwood, Lancashire, FY7 8RY, England · +44 (0) 1253 858787 · Fax: +44 (0) 1253-859595 · [www.vtronix-antennas.com](http://www.vtronix-antennas.com)